PETER-HOLMBERG PVC WINDOW AND DOOR INSTALLATION GUIDE

Handling and storage conditions

- Transport and store only in an upright position.
- The product must be placed on a flat surface to prevent injury and breakage.
- The product must be protected from precipitation, excessive moisture, dirt, paint and dust from building work.
- Do not drag or drop the windows

Installation

- 1. Remove protection cover film on frame prior to facial board installation
- 2. Install facial boards to one side of the window as shown on Figure 1 (NB! Pre-drill screw hoes)
- 3. Insert window into opening
 - 3.1. It is recommended to apply insulation material (rock-wool or self-expending gasket) around the window
 - 3.2. Make shore the window is level
 - 3.2.1. If not use wedges to level the window
- 4. Install the facial boards from other side

Figure 1 – Facial board installation:

